



TRANSFER

CONTENTS

TRANSFER (Model : T130A)	TF- 2	TRANSFER CONTROL	TF-20
REMOVAL AND INSTALLATION	TF- 4	SERVICE DATA AND SPECIFICATIONS	TF-22
FORKS AND FORK RODS	TF- 4	GENERAL SPECIFICATIONS.....	TF-22
GEARS AND SHAFTS	TF- 5	INSPECTION AND ADJUSTMENT	
OIL SEALS	TF- 7	(Model: T130A)	TF-23
BEARINGS.....	TF- 8	INSPECTION AND ADJUSTMENT	
TRANSFER CASE AND COVERS	TF- 9	(Model: T100L)	TF-23
TRANSFER CONTROL	TF- 9	TIGHTENING TORQUE.....	TF-24
TRANSFER (Model : T100L)	TF-10	TROUBLE DIAGNOSES AND CORRECTIONS	TF-25
REMOVAL AND INSTALLATION	TF-11	SPECIAL SERVICE TOOLS	TF-28
FORKS AND FORK RODS	TF-12		
GEARS AND SHAFTS	TF-16		
TRANSFER CASE FRONT COVER, TRANSFER FRONT CASE AND TRANSFER REAR CASE (Replacement of oil seals and bearings)	TF-19		

TRANSFER (Model : T130A)





- Note: a. Apply sealant when reinstalling seal bolt.
 b. The following parts should be replaced with new one at every disassembly.
- Oil seal
 - O-ring
 - Gasket
 - Companion flange lock nut
 - Snap ring

Ⓣ : N·m (kg·m, ft·lb)

SMT257


REMOVAL AND INSTALLATION

Refer to Section MT.


FORKS AND FORK RODS

DISASSEMBLY


1. Remove transfer with transmission from vehicle. Refer to Section MT for removal.
2. Drain transfer oil prior to disassembly.




3. Remove center brake assembly and each companion flange.
4. Remove upper cover from transfer.
5. Remove transfer outer lever.




6. Remove rear drive shaft cover.




7. Remove retaining ring from front drive fork rod.




8. Remove dowel pin from Low & High shift fork using Tool.




9. Remove front drive shaft cover assembly.




10. Remove snap ring and front drive shift fork.
11. Remove check ball plug, check spring and check ball for front drive fork rod.




12. Remove snap ring and shift shaft assembly.




13. Pull front drive fork rod out, then remove interlock plunger.



14. Pull Low & High fork rod out, then remove check ball and check spring for Low & High fork rod.




15. Disassemble front drive shift fork.
16. Fork guide collar and spring can be removed by removing retaining ring.



INSPECTION


1. Clean with solvent, and check forks for wear, scratches, projection, damage or other defects. Replace any part which is worn or damaged.
2. Check fork rods for bend, scratches, and check groove of check ball for wear as illustrated.



ASSEMBLY

Assemble fork and fork rods in the reverse order of disassembly, noting following points.

- Install check ball, check spring and interlock plunger to their original positions.
- When installing fork rods, pay attention to the direction of their grooves.
- Push Low & High fork rod until check ball fits securely into 3rd groove.



- 1 Check spring
- 2 Check ball
- 3 Interlock plunger
- 4 Low & High fork rod
- 5 Front drive fork rod
- 6 Plug

- Always install new gasket on front cover and rear drive shaft cover.
- Apply sealant to check ball hole plug.
- Apply sealant to three rear drive shaft cover mounting bolts for through holes.

Ⓣ : Check ball hole plug

15 - 20 N·m
(1.5 - 2.0 kg·m,
11 - 14 ft·lb)

Front drive shaft cover bolt

26 - 36 N·m
(2.7 - 3.7 kg·m,
20 - 27 ft·lb)

Rear drive shaft cover bolt A
(Seal bolt)

29 - 39 N·m
(3 - 4 kg·m,
22 - 29 ft·lb)

Rear drive shaft cover bolt B

26 - 36 N·m
(2.7 - 3.7 kg·m,
20 - 27 ft·lb)

Upper cover bolt

8 - 11 N·m
(0.8 - 1.1 kg·m,
5.8 - 8.0 ft·lb)

Shift rod lock pin nut

9 - 12 N·m
(0.9 - 1.2 kg·m,
6.5 - 8.7 ft·lb)

Filler plug

20 - 27 N·m
(2.0 - 2.8 kg·m,
14 - 20 ft·lb)

Drain plug

29 - 39 N·m
(3 - 4 kg·m,
22 - 29 ft·lb)

Transfer oil capacity:

1.8ℓ (3-1/8 Imp pt)

GEARS AND SHAFTS

DISASSEMBLY AND ASSEMBLY

Transfer main gear, counter gear and countershaft

Refer to Section MT for disassembly.


When assembling gears and shafts, observe following points.

- Apply a coat of grease to counter gear thrust washer, and countershaft and mainshaft needle bearings.
- Always install new O-rings and gaskets.
- Apply sealant to three mainshaft cover mounting bolts for through holes.

Front drive shaft


First remove front companion flange before disassembling.

1. Remove front drive shaft cover. Refer to Fork and Fork Rods for disassembly.
2. Remove front drive shaft from front drive shaft cover.



3. Install front drive shaft.


When pressing front drive shaft, ball bearing inner race should receive pressing force.




4. Install front drive shaft cover. Refer to Forks and Fork Rods.

Rear drive shaft and transfer High/Low gear

1. Remove front cover with fork, fork rods and front drive shaft. Refer to Forks and Fork Rods for removal.




2. Drive rear end of rear drive shafts until front bearing is driven out of transfer case.




Use a copper hammer for driving.

3. Remove snap ring, and front ball bearing as necessary using a suitable puller.




4. Separate the following parts from rear drive shaft.




Be careful not to lose steel ball (used on inner side of thrust washer).

5. Separate the following parts from rear drive shaft.




6. Remove rear ball bearing from transfer case as necessary and install new bearing using suitable drift.



Press rear bearing until it butts against bearing retainer.


7. Install gears and shaft in the reverse order of removal, noting the following.

- When installing front ball bearing onto shaft, always receive inner race until bearing butts against thrust washer.



- When assembling rear drive shaft to transfer case, press both inner and outer front bearings with a press and drifts so that pressing forces are always imposed upon rear outer and inner ball bearings.

CAUTION:
Engage coupling sleeve to match serration of High/Low gear and press fit them.



- After assembly, make sure that gears and coupling sleeves move smoothly without any binding.

INSPECTION

1. Check gears for excessive wear, chips or cracks; replace as required.
2. Check shaft for bend, crack, wear, and worn spline; if necessary, replace.

OIL SEALS


INSPECTION

1. Check seal portions of front drive shaft, shift shaft and rear drive shaft for oil leaks. Replace oil seal as necessary.
2. Check countershaft O-ring and speedometer driven gear O-ring for leaks. Replace O-rings as necessary.
3. Check gaskets of upper cover, mainshaft cover, rear cover, front drive shaft cover and transfer case for oil leaks. Replace gaskets as necessary.

REPLACEMENT

Front drive shaft oil seal

1. Remove front drive shaft cover, and remove front drive shaft from cover. Refer to Front Drive Shaft for removal.
2. Remove oil seal.
3. Apply grease to cavity between seal lips and install oil seal using Tool.



Be careful not to scratch sealing lips or damage oil seals.

- Ⓣ : Front drive shaft nut
245 - 333 N·m
(25 - 34 kg·m,
181 - 246 ft·lb)

- Front propeller shaft to companion flange
78 - 88 N·m
(8 - 9 kg·m,
58 - 65 ft·lb)


Rear drive shaft oil seal and rear drive shaft cover gasket

Rear drive shaft oil seal and rear cover gasket can be replaced without removing transfer from vehicle.

1. Drain transfer oil.
2. Disconnect rear propeller shaft.
3. Remove center brake.
4. Remove rear drive shaft cover to replace gasket.
5. Remove oil seal as necessary.

Oil seal once removed should not be used again.

6. Apply grease to cavity between seal lips and install oil seal using Tool.



Be careful not to scratch sealing lips or damage oil seals.

7. Install in the reverse order of removal.

Apply sealant to three rear drive shaft cover mounting bolts for through holes.

- Ⓣ : Rear drive shaft cover mounting bolt

- 29 - 39 N·m
(3 - 4 kg·m,
22 - 29 ft·lb)

Center brake securing bolt

- 26 - 36 N·m
(2.7 - 3.7 kg·m,
20 - 27 ft·lb)

Rear drive shaft nut

- 245 - 333 N·m
(25 - 34 kg·m,
181 - 246 ft·lb)

Rear propeller shaft to brake drum


- 78 - 88 N·m
(8 - 9 kg·m,
58 - 65 ft·lb)

Main drive shaft oil seal and transfer case gasket

1. Remove transfer with transmission, and separate transfer from transmission. Refer to Section MT for removal.
2. Remove oil seal as necessary using suitable drift.

Oil seal once removed should not be used again.

3. Apply a coat of gear oil to new oil seal surface, and install it using Tool.



Be careful not to scratch sealing lips or damage oil seals.

4. Apply a coat of grease to sealing lips.


5. Replace transfer case gasket.

Install in the reverse order of removal noting the following.

When installing transfer unit on transmission, be careful not to damage or fold oil seal lips with main drive shaft.

Countershaft O-ring

1. Remove countershaft lock plate.
2. Drive countershaft out until O-ring is visible.




Do not drive out countershaft more than 30 mm (1.18 in). Doing so can cause needle bearing to drop, resulting in assembly difficulties.

3. Replace O-ring.

Apply a coat of grease to new O-ring and O-ring groove.

Upper cover gasket

1. Straighten straps. Remove bolts and upper cover.



2. Replace gasket.


After assembly, be sure to bend straps securely.

- Ⓣ : Upper cover securing bolt
8 - 11 N·m
(0.8 - 1.1 kg-m,
5.8 - 8.0 ft-lb)

Mainshaft cover gasket

1. Remove mainshaft cover.

Be careful not to drop needle bearings (used on inner side of cover).



2. Replace gasket

- Ⓣ : Mainshaft cover securing bolt A (Seal bolt)
29 - 39 N·m
(3 - 4 kg-m,
22 - 29 ft-lb)
- Mainshaft cover securing bolt B
26 - 36 N·m
(2.7 - 3.7 kg-m,
20 - 27 ft-lb)

Apply sealant to three mainshaft cover securing bolts for through holes.

Front drive shaft cover gasket

In replacing front cover gasket it is necessary to remove transfer from vehicle as a unit with transmission.

1. Remove front cover with front drive shaft and fork rods, referring to Forks and Fork Rods for removal.
2. Replace gasket.
3. Install in the reverse order of removal.


BEARINGS REPLACEMENT

Front drive shaft bearing


1. Remove front drive shaft oil seal. Refer to Oil Seals for removal.

Oil seal once removed should not be used again.

2. Remove snap ring.
3. Remove front drive shaft bearing using suitable drift.



4. Install new bearing.
Always press bearing outer race.
5. Install snap ring.



6. Install new oil seal.

Rear drive shaft bearings


Refer to Rear Drive Shaft and Transfer High/Low Gear for replacement.

Countershaft bearings

Refer to Counter Gear and Countershaft for replacement.

Mainshaft needle bearing

Remove mainshaft cover, and remove needle bearing.



- Affix needle bearings to their original positions, applying grease.
- Always install new gaskets.
- Apply sealant to three mainshaft cover securing bolts for through holes.

Ⓣ : Mainshaft cover securing bolt A (Seal bolt)

29 - 39 N·m
(3 - 4 kg·m,
22 - 29 ft·lb)

Mainshaft cover securing bolt B


26 - 36 N·m
(2.7 - 3.7 kg·m,
20 - 27 ft·lb)

INSPECTION

1. Thoroughly clean bearing and dry with compressed air.

CAUTION:

Do not allow the bearings to spin. Because it will damage the race and balls. Turn them slowly by hand.



2. When race and ball surfaces are worn or rough, or when balls are out-of-round or rough, replace bearing with a new one.
3. Replace needle bearing if worn or damaged.

TRANSFER CASE AND COVERS

INSPECTION


1. Clean with solvent and check for cracks or pits by means of dyeing test.
2. Check mating surface of transmission case for small nicks, projection or sealant.

TRANSFER CONTROL

REMOVAL AND INSTALLATION

Transfer control lever

1. Remove control lever boots.
2. Remove floor hole cover.
3. Remove nut and control lever pin.




Cross shaft

It is required to remove transfer with transmission from vehicle.

Refer to Section MT for removal.


1. Remove transmission shift cover.
2. Remove screw, then draw cross shaft out.





3. Replace cross shaft seals as necessary.


Outer lever

Remove nut and outer lever pin.




TRANSFER (Model : T100L)






REMOVAL AND INSTALLATION



REMOVAL

1. Disconnect battery ground cable.
2. Jack up vehicle and support its weight on safety stands. Use a hydraulic hoist or open pit, if available.
3. Disconnect propeller shafts. Refer to Propeller Shaft (Section PD) for removal.
4. Disconnect wire for 4-wheel drive switch.
5. Disconnect speedometer cable.
6. Support transfer with a jack.
7. Disconnect transfer control rod.



8. Disconnect brake cable from control lever and pull the wire to transfer side. Refer to Center Brake (Section BR).
9. Remove transfer mounting member attaching bolts, and remove transfer unit with mounting member.
10. Remove mounting brackets and mounting insulator.

INSTALLATION

Install transfer in reverse order of removal, observing the following.

- Ⓣ : Mounting member to side member
72 - 96 N·m
(7.3 - 9.8 kg·m,
53 - 71 ft·lb)

Mounting insulator to mounting bracket

16 - 21 N·m
(1.6 - 2.1 kg·m,
12 - 15 ft·lb)

Mounting bracket to mounting member


38 - 51 N·m
(3.9 - 5.2 kg·m,
28 - 38 ft·lb)

Mounting insulator to transfer

38 - 51 N·m
(3.9 - 5.2 kg·m,
28 - 38 ft·lb)

Oil capacity:
1.4ℓ (2-1/2 Imp pt)


6. Remove transfer case front cover by tapping it with soft faced hammer.




FORKS AND FORK RODS

DISASSEMBLY


1. Wipe off dirt and grease.
2. Drain oil.
3. Remove companion flange lock nuts.




7. Remove FR drive shaft and needle bearing.




4. Remove companion flanges.
5. Remove 4WD switch.




8. Remove snap ring retaining FR shift fork, then remove FR shift fork assembly and spacer together with coupling sleeve.




9. Remove snap ring retaining coupling sleeve hub.




Do not pry transfer front or rear cases with screwdriver.




16. Remove check ball plug, check spring and check ball.




10. Remove coupling sleeve hub.




13. Remove cotter pin nut, then remove cotter pin by tapping it with hammer.




17. Drive out High & Low shift fork retaining pin.



11. Remove transfer front case securing bolts.



14. Remove cross shift shaft.




18. Tap rear end of transfer case drive shaft assembly, then remove it with High & Low shift fork and counter gear assembly. Transfer case main gear assembly can be pulled out.

When removing counter gear assembly, be careful not to drop needle bearings.


Remove transfer case front shim.

Be careful not to lose shim.



12. Remove transfer front case by tapping it with soft faced hammer.


15. Remove shift lever with differential lever.



19. Remove High & Low and FR fork rods, interlock plunger, steel ball and check spring.


20. Place FR fork rod in a vise, then drive out retaining pin.

FR fork rod bracket can be removed.




21. Insert M8 bolt into FR shift fork and tighten nut to eliminate shift fork spring tension.

Remove snap ring with snap ring plier.




22. Remove spring retainer bushings and shift fork spring. Separate spring retainer bushing and shift fork spring.



INSPECTION


Clean with solvent and check for wear, scratches, projection, damage or other faulty conditions. Replace any part which is worn or damaged.



ASSEMBLY

1. Install breather cover, then install transfer main gear assembly by tapping it.


2. Drive out FR shift fork welch plug. This step is necessary for installing FR shift fork.



3. Install check spring and steel ball into hole of transfer rear case.


4. Using Tool, retain steel ball.

Be careful not to lose check ball and steel ball as the spring force may force them out.




5. Install High & Low shift fork into coupling sleeve.

6. Place FR fork rod in a vise, then install retaining pin.




7. Install FR fork rod pushing Tool ST23620000 out of position. Install interlock pin.



8. Secure FR fork rod bracket to FR fork rod with retaining pin.

9. Assemble snap ring, spring retainer bushings and shift fork spring to FR shift fork. Insert M8 bolt into spring retainer bushing and tighten nut to eliminate spring tension.



10. Install the other snap ring. Remove bolt and nut.


11. Install new O-ring to countershaft, then install it to transfer rear case.

When installing O-ring, be sure to apply gear oil to it.

12. Install counter gear assembly.


Make sure that counter gear thrust washer is already installed.

13. While raising counter gear assembly slightly, install transfer case drive shaft assembly and engage each gear.




14. Install companion flange at rear side of drive shaft, and tighten finger tight.


15. Tap front end of drive shaft assembly and install it into transfer rear case.



16. Install High & Low fork rod, then secure with retaining pin.




17. Apply sealant to hole of welch plug in transfer rear case and install welch plug in it.



18. Install check ball and check spring.


19. Apply sealant to threads of plug, then tighten it.

Ⓘ : 19 - 25 N·m
(1.9 - 2.5 kg·m,
14 - 18 ft·lb)




20. Select snap ring so that end play is within specified limit.

Coupling sleeve hub end play:
0 - 0.20 mm (0 - 0.0079 in)
Coupling sleeve hub snap ring:
Refer to S.D.S.




21. Install coupling sleeve hub, then secure with snap ring.




22. Install shift lever with differential lever.

23. Install cross shift shaft.





24. Apply grease to thrust washer, main gear front and transfer case front shims selected, then attach them to transfer front case.




- 25. Clean mating surface of transfer front case.
- 26. Apply sealant to mating surface of transfer front case.

Apply sealant continuously.




- 30. Install FR drive shaft to transfer case drive shaft.
- 31. Clean mating surface of transfer front case, then apply sealant to mating surface of it.

Apply sealant continuously.




- 27. Install transfer front case by tapping it with soft faced hammer.



Ⓣ : Transfer front case securing bolt
8 - 11 N-m
(0.8 - 1.1 kg-m,
5.8 - 8.0 ft-lb)

- 28. Install spacer, FR shift fork assembly with coupling sleeve and spacer, then secure with snap ring.



- 29. Apply gear oil to pilot bearing, then install it in place.

GEARS AND SHAFTS


DISASSEMBLY

Counter gear and transfer case main gear


- 1. Remove transfer case drive shaft assembly, counter gear assembly, forks and fork rods.

Refer to Forks and Fork Rods for disassembly.


- 2. Remove transfer main gear and breather cover from transfer rear case.
- 3. Remove transfer main gear front bearing.




- 4. Remove transfer main gear rear bearing.



- 5. Remove needle bearings, center spacer and spacer from counter gear.



- 32. Install transfer case front cover.



- 33. Install companion flanges.

Lock nuts are self-lock type so always use new lock nut.


Ⓣ : 118 - 137 N-m
(12 - 14 kg-m,
87 - 101 ft-lb)

- 34. Install 4WD switch.


Ⓣ : 20 - 29 N-m
(2 - 3 kg-m,
14 - 22 ft-lb)

Low gear

1. Press out drive shaft front ball bearing.



2. Remove spacer and steel ball.
Be careful not to lose steel ball retaining spacer.
3. Press out drive shaft rear ball bearing with suitable plate or puller.




- Standard end play:**
- High gear
0.10 - 0.20 mm
(0.0039 - 0.0079 in)
 - Low gear
0.10 - 0.20 mm
(0.0039 - 0.0079 in)
 - Coupling sleeve hub
0 - 0.20 mm
(0 - 0.0079 in)

Bearings

Refer to Transfer Front Cover for inspection.

2. Remove thrust washer and steel ball.
Be careful not to lose steel ball retaining thrust washer.
3. Remove Low gear and needle bearings.



4. Remove thrust washer and steel ball.
Be careful not to lose steel ball retaining thrust washer.
5. Remove High gear, needle bearings and coupling sleeve.

ASSEMBLY

High gear

1. Apply gear oil to needle bearings and install needle bearings and High gear onto transfer case drive shaft.
2. Apply grease to steel ball and thrust washer, then attach them to High gear.
3. Press drive shaft rear ball bearing.


INSPECTION

Gear and shafts

Check all gears for excessive wear, chips or cracks; replace as required.

Measure gear end play:



- It is necessary to measure end play before disassembling transfer case drive shaft and after reassembling transfer case drive shaft.
- If end play is not within specified limit, disassemble and check parts for condition.
- Replace any part which is worn or damaged.



When pressing it, be sure to hold High gear by hand so as not to drop thrust washer.

High gear

1. Remove speedometer worm gear.




4. Install drive shaft spacer. Apply grease to steel ball, then install steel ball and speedometer worm gear.

Low gear

5. Apply gear oil to needle bearing and install needle bearings, coupling sleeve and Low gear.
6. Apply grease to steel ball and thrust washer, then attach them to Low gear.

7. Press drive shaft front ball bearing.





When pressing it, be sure to hold Low gear by hand so as not to drop thrust washer.



Selection of shims

If thrust washer, each ball bearing, drive shaft, transfer front & rear cases or transfer case main gear is replaced, it is necessary to select each shim.

1. Measure bearing insertion lengths A and B for transfer front case.




2. Measure bearing insertion lengths C and D for transfer rear case.



When measuring C, be sure to install breather cover in its position.

3. Measure distance E between ball bearing outer races of transfer main gear.



4. Measure distance F between ball bearing outer races of transfer drive shaft.

5. Select shims as follows:

5-1 Calculate L_1 and L_2 by using the following equations:

$$L_1 = A + C - E$$

$$L_2 = B + D - F$$


5-2 Determine shim thickness by using values L_1 and L_2 .

Main gear front and transfer case front shims.


Refer to S.D.S.

Transfer case main gear and counter gear


1. Press transfer case main gear front bearing.



2. Press transfer case main gear rear bearing.





3. Install breather cover and transfer case main gear.



4. Apply grease to all needle bearings and spacers.

5. Install center spacer to counter gear, then assemble needle bearings and spacers in counter gear.



- a. Use 28 needle bearing (14 on each side).
- b. After attaching needle bearings in place, apply grease thickly so that bearing does not come off.

6. Install transfer case drive shaft assembly, forks and fork rods.
Refer to Forks and Fork Rods for assembly.

TRANSFER CASE FRONT COVER, TRANSFER FRONT CASE AND TRANSFER REAR CASE (Replacement of oil seals and bearings)

Disassembly and assembly procedures for above cases are the same as those of gears and shafts. Refer to Gears and Shafts for disassembly and assembly.

Described below are replacement procedures for oil seal, bearing and cases after disassembling cases.


For replacement of main gear front, rear bearing, drive shaft front and rear bearing, refer to Disassembly and Assembly of Gears and Shafts.

TRANSFER FRONT COVER


Disassembly

1. Remove oil seal.

2. Remove snap ring.



3. Remove bearing.



Inspection

Oil seals


1. Replace oil seal if sealing lip is deformed or cracked. Also discard oil seal if spring is out of position.
2. Check the oil seal lip contacting with shaft; if necessary replace oil seal and shaft as a set.

Bearings

1. Thoroughly clean bearing and dry with compressed air.

CAUTION:

Do not allow the bearings to spin. Because it will damage the race and balls. Turn them slowly by hand.




2. When race and ball surfaces are worn or rough, or when balls are out-of-round or rough, replace bearing with a new one.
3. Replace needle bearing if worn or damaged.

Transfer case front cover


1. Clean with solvent and check for cracks or pits by means of dyeing test.
2. Check mating surface of transmission case for small nicks, projection or sealant.

Assembly

1. Press bearing.




2. Install snap ring with snap ring pliers.
3. Apply coat of gear oil to oil seal surface, then drive new seal into place.



TRANSFER FRONT AND REAR CASE


Disassembly

Remove oil seal.



Assembly

1. Apply coat of gear oil to oil seal surface, then drive new seal into place.




4. Lubricate seal lip with gear oil.

Inspection

Refer to Transfer Front Cover for inspection.


2. Lubricate seal lip with gear oil.

TRANSFER CONTROL REMOVAL AND INSTALLATION



Transfer control lever

1. Disconnect control rod from control lever.
2. Remove control lever cover.
3. Remove nut and control lever pin, and remove control lever.




Control rod


Remove snap pins from both ends of control rod and remove it.

ADJUSTMENT

1. Set lever on transfer side in "2H" position.



2. Provide a clearance of more than 48 mm (1.89 in) between control lever and heater unit. Then connect rod to control lever.



3. Set control lever in "4L" position and make sure there is a clearance of more than 50 mm (1.97 in) between control lever and hand brake.
4. Make sure that the force required for operating control lever is within 39 to 78 N (4 to 8 kg, 9 to 18 lb).

SERVICE DATA AND SPECIFICATIONS

GENERAL SPECIFICATIONS

Transfer model		T130A		T100L			
Shift type		<ul style="list-style-type: none"> ● 2H ● 4H ● N ● 4L 					
Gear ratio	High	1.000					
	Low	2.220		2.074			
Combined gear ratio with F4W81A transmission	High	1st	3.519				
		2nd	2.157				
		3rd	1.449				
		4th	1.000				
		Rev.	4.181				
	Low	1st	7.812	7.298			
		2nd	4.789	4.474			
		3rd	3.217	3.005			
		4th	2.220	2.074			
		Rev.	9.282	8.671			
Combined gear ratio with 3N71B transmission	High	1st	-				
		2nd	-				
		Top	-				
		Rev.	-				
	Low	1st	-				
		2nd	-				
		Top	-				
		Rev.	-				
Number of teeth	Main gear		30		29		
	Counter gear	High	48		41		
		Low	35		30		
	Transfer case	High	30		29		
Low		34		44			
Speedometer gear ratio	Tire size		6.50-16	205R16C 7.00-16 7.50-16	6.50-16	205R16C 7.50-16	
	Final ratio		3.364	6/16	6/13	-	-
			4.111	6/17	6/16	-	-
			4.375	6/18	6/17	6/18	6/17
			4.625	6/19	6/18	6/19	6/18
Oil capacity		ℓ (Imp pt)		1.8 (3-1/8)		1.4 (2-1/2)	

**INSPECTION AND ADJUSTMENT
(Model : T130A)**

High gear end play	mm (in)	0.20 - 0.35 (0.0079 - 0.0138)
Low gear end play	mm (in)	0.20 - 0.35 (0.0079 - 0.0138)

**INSPECTION AND ADJUSTMENT
(Model : T100L)****GEAR END PLAY**

Unit: mm (in)

High gear	0.10 - 0.20 (0.0039 - 0.0079)
Low gear	0.10 - 0.20 (0.0039 - 0.0079)
Coupling sleeve hub	0 - 0.20 (0 - 0.0079)

AVAILABLE SNAP RING**Coupling sleeve hub**

Thickness mm (in)	Part number
1.3 (0.051)	33145 C6903
1.4 (0.055)	33145 C6904
1.5 (0.059)	33145 C6900
1.6 (0.063)	33145 C6901
1.7 (0.067)	33145 C6902

AVAILABLE SHIM**Main gear front**

Unit: mm (in)

"L ₁ "	Thickness of shim	Part Number
0.06 - 0.15 (0.0024 - 0.0059)	—	—
0.16 - 0.25 (0.0063 - 0.0098)	0.10 (0.0039)	33112 C6900
0.26 - 0.35 (0.0102 - 0.0138)	0.20 (0.0079)	33112 C6901
0.36 - 0.45 (0.0142 - 0.0177)	0.30 (0.0118)	33112 C6902
0.46 - 0.55 (0.0181 - 0.0217)	0.40 (0.0157)	33112 C6903

Transfer case front

Unit: mm (in)

"L ₂ "	Thickness of shim	Part Number
0 - 0.13 (0 - 0.0051)	—	—
0.14 - 0.23 (0.0055 - 0.0091)	0.10 (0.0039)	33147 C6900
0.24 - 0.33 (0.0094 - 0.0130)	0.20 (0.0079)	33147 C6901
0.34 - 0.43 (0.0134 - 0.0169)	0.30 (0.0118)	33147 C6902
0.44 - 0.53 (0.0173 - 0.0209)	0.40 (0.0157)	33147 C6903

TIGHTENING TORQUE


MODEL T130A


Unit	N-m	kg-m	ft-lb
Transfer installation			
Front and rear propeller shaft	78 - 88	8 - 9	58 - 65
Transfer mounting bracket to transfer	27 - 36	2.8 - 3.7	20 - 27
Insulator to transfer mounting bracket	17 - 22	1.7 - 2.2	12 - 16
Insulator to frame	30 - 41	3.1 - 4.2	22 - 30
Rear companion flange	245 - 333	25 - 34	181 - 246
Transfer unit			
Drain plug	29 - 39	3 - 4	22 - 29
Filler plug	20 - 27	2.0 - 2.8	14 - 20
Transfer upper cover	8 - 11	0.8 - 1.1	5.8 - 8.0
Mainshaft cover A (Seal bolt)	29 - 39	3 - 4	22 - 29
Mainshaft cover B	26 - 36	2.7 - 3.7	20 - 27
Main gear lock nut	196 - 333	20 - 34	145 - 246
Countershaft lock bolt	14 - 18	1.4 - 1.8	10 - 13
Transfer to transmission A (Seal bolt)	20 - 27	2.0 - 2.8	14 - 20
Transfer to transmission B (Seal bolt)	20 - 27	2.0 - 2.8	14 - 20
Transfer to transmission C	18 - 25	1.8 - 2.5	13 - 18
Transfer to transmission D	18 - 25	1.8 - 2.5	13 - 18
Transfer to transmission E	18 - 25	1.8 - 2.5	13 - 18
Shift lever lock nut	9 - 12	0.9 - 1.2	6.5 - 8.7
Front companion flange	245 - 333	25 - 34	181 - 246
Front cover	26 - 36	2.7 - 3.7	20 - 27
Check ball hole plug	15 - 20	1.5 - 2.0	11 - 14
Center brake drum	78 - 88	8 - 9	58 - 65
Center brake assembly	26 - 36	2.7 - 3.7	20 - 27
Rear drive shaft cover A (Seal bolt)	29 - 39	3 - 4	22 - 29
Rear drive shaft cover B	26 - 36	2.7 - 3.7	20 - 27
Speedometer sleeve lock bolt	3 - 4	0.3 - 0.4	2.2 - 2.9
Breather	10 - 13	1.0 - 1.3	7 - 9


MODEL T100L

Unit	N-m	kg-m	ft-lb
Transfer installation			
Mounting member to side member	72 - 96	7.3 - 9.8	53 - 71
Mounting insulator to mounting bracket	16 - 21	1.6 - 2.1	12 - 15
Mounting bracket to mounting member	38 - 51	3.9 - 5.2	28 - 38
Mounting insulator to transfer	38 - 51	3.9 - 5.2	28 - 38
Transfer unit			
Check ball plug	19 - 25	1.9 - 2.5	14 - 18
Cotter pin	9 - 12	0.9 - 1.2	6.5 - 8.7
Transfer front case	8 - 11	0.8 - 1.1	5.8 - 8.0
Transfer case front cover	8 - 11	0.8 - 1.1	5.8 - 8.0
4WD switch	20 - 29	2 - 3	14 - 22
Companion flange	118 - 137	12 - 14	87 - 101
Drain plug	20 - 39	2 - 4	14 - 29
Filler plug	20 - 39	2 - 4	14 - 29
Speedometer sleeve	3 - 4	0.3 - 0.4	2.2 - 2.9











TROUBLE DIAGNOSES AND CORRECTIONS








SPECIAL SERVICE TOOLS

Tool number	Tool name	T130A	T100L
ST23540000	Fork rod pin punch 	X	-
KV40100621	Oil seal drift 	X	-
ST30720000	Oil seal drift 	X	-
KV38104700	Companion flange wrench 	-	X
KV31100300	Fork rod pin punch 	-	X
ST23620000	Fork rod guide 	-	X
ST22730000	Bearing puller 	-	X
ST30701000	Bearing drift 	-	X
ST19820000	Bearing drift 	-	X
ST37750000	Bearing drift 	-	X

TRANSFER – *Special Service Tools*

Tool number	Tool name	T130A	T100L
KV38102100	Oil seal drift 	-	X